







Step 2 Next, slide (1) Top Panel (closed hole sockets) on 36" legs. Make sure panel is pushed all the way down as shown.

